

DESCRIPTION

- Brass construction
- Flexible supply lines with 3/8" fittings
- Includes Red/Blue indicators

CARTRIDGE

Ceramic disk cartridge


STANDARDS

ADA for lever handle

Specifications



Single-Handle Lavatory Faucet NOTE: THIS FAUCET IS DESIGNED TO BE INSTALLED THRU 1 HOLE/3 HOLES.



CRITICAL DIMENSIONS



INSTALLATION MANUAL Tools:












Adjustable wrench Hexagon wrench Notes before installation :


- 1.Please check that all components are present.
- 2.Before installation ensure that all feed lines are clear of debris and on/off valve is present.
- 3.Ensure water pressure is between 20-125 PSI (includes combination of hot and cold feed lines).
- 4. Pictures in the manual are general in content and may not represent exactly your purchased faucet. If you are having difficulties please contact a professional plumber.
- 5.If you will be away from home for an extended period you should shut off the main water supply.

Daily maintenance


- 1.Use a soft cloth and vinegar to remove hard-water spots.
- Check aerator (if present) regularly for calcium build up are when water stream is not optimum.
- 3.DO NOT use caustic cleaning products as the use will break down finish and will void the product warranty.
- 4. Acceptable cleaners include vinegar or mild non-abrasive liquid detergents.
- 5.If the water pressure appears to be less than optimum remove, inspect, clean or replace aerator.




1. Remove the rubber washer, metal washer and locking nut from the faucet.




cold flexible hoses to the faucet.DO NOT use a wrench to tighten hoses as this may damage the hose and/or the hose threads.



3. Install faucet through center hole .




4. Re-install the rubber washer followed by the metal washer and lock-nut.Hand tighten then tighten further using a screw driver to tighten lock-nut screws.





Run the hot and cold valve at least 15 seconds to clear it before connect Noise could be significantly

reduced by adjusting the valve water flow



- 1 Drain Cap
- 2 Silicon Gasket
- 3 Sponge Gasket
- 4 Silicon Gasket 5 Drain Body

6 Overflow

- 7 Silicon Gasket
- 8 Plastic Washer
- 9 Brass Locking Nut
- 10 Rubber Ggsket 11 Locking Nut

12 Tail Pipe

